

CompTIA A+ Core 1 Playbook

IT Labs

Prepared by Garrick White

2.1.16 Set Up a Desktop Computer

You are the IT administrator for a small corporate network. You just received a new computer and you are setting it up in your office.

- Plug a power strip into the wall.
- Plug the computer into the power strip.
- Connect the following components to the computer:
 - Keyboard
 - Mouse
 - Speakers
- Add the following objects to the bench and connect them to the computer using the appropriate cables:
 - Monitor
 - Printer
- Plug the following devices into the power strip:
 - Monitor
 - Printer
- Connect the computer to the network port on the wall plate.

Explanation

Complete this lab as follows:

1. Plug in a power strip.
 1. Under Inventory, expand **Electrical Outlets**.
 2. Drag the **Power Strip** to the wall outlet.
2. Provide power to the computer.
 1. Switch to the **Back** view of the computer.
 2. Under Inventory, expand **Cables**.
 3. Select **AC Power Cable**.
 4. From the Selected Item pane:
 - Drag the **AC Power Connector (Male)** to an outlet on the power strip.
 - Drag the **AC Power Connector (Female)** to the power plug on the back of the computer.
3. Connect the keyboard.
 1. Under Inventory, expand **Peripherals**.
 2. Drag the **Keyboard** to a USB port on the back of the computer.
4. Connect the mouse.
 1. From the Inventory, drag the **Mouse** to a USB port on the back of the computer.
5. Connect the speakers.
 1. From the Inventory, drag the **Speakers** to the green mini-TRS port on the back of the computer.
6. Connect the monitor to the computer.
 1. Drag the **monitor** from the Inventory and to the Workspace.
 2. Switch to the **Back** view of the monitor.
 3. Under Inventory, expand **Cables**.
 4. Select **DVI-D to DVI-D**.
 5. From the Selected Item pane:
 - Drag a **DVI-D Connector** to the DVI-I port on the back of the monitor.
 - Drag the other **DVI-D Connector** to the DVI-I port on the back of the computer.
7. Plug the monitor into the power strip.
 1. Under Inventory, select **AC Power Cable**.
 2. From the Selected Item pane:
 - Drag the **AC Power Connector (Male)** to an outlet on the power strip

- in the Workspace.
 - Drag the **AC Power Connector (Female)** to the power plug on the back of the monitor.
8. Connect the printer.
1. Under Inventory, expand **Peripherals**.
 2. Drag the **Inket Printer** to the Workspace.
 3. Switch to the **Back** view of the printer.
 4. Under Inventory, expand **Cables**.
 5. Select **USB Cable (A/B)**.
 6. From the Selected Item pane:
 - Drag the **USB Type B Connector** to the USB port on the back of the printer.
 - Drag the **USB Type A Connector** to a USB port on the back of the computer.
9. Provide power to the printer.
1. Under Inventory, select **Power Adapter for HP**.
 2. From the Selected Item pane:
 - Drag the **DC power connector** to the power port on the printer.
 - Drag the **AC power connector** to an outlet on the power strip in the Workspace.
10. Connect the computer to the network.
1. Under Inventory, select the **Cat6a cable**.
 2. From the Selected Item pane:
 - Drag an **RJ45 connector** to the RJ45 port on the back of the computer.
 - Drag the other **RJ45 connector** to the RJ45 port on the wall plate.