

CompTIA A+ Core 1 Playbook

IT Labs

Prepared by Garrick White

5.2.2 Select and Install a Network Adapter

You work as the IT administrator for a small corporate network. To accommodate specific network communication needs for an upcoming project, you need to upgrade the network connection's speed for the Windows workstation located in the Executive Office.

In this lab, your task is to:

- Install the network interface card with the fastest speed into the Exec computer.
- Connect the Exec computer to the local area network using the new network card and the appropriate cable.
- From the workstation's operating system, use the **ping** command to confirm that the workstation has a connection to the local network and the internet using the following:
 - Local server IP address: **192.168.0.10**
 - ISP & internet provider: **198.28.2.254**

Complete this lab as follows:

1. Insert the PCI adapter into the motherboard.
 1. Switch to the **Motherboard** view of the computer.
 2. In the Inventory, expand **GPUs/Expansion Cards**.
 3. Drag the brown **Network Adapter, Ethernet 10/100/1000BaseTX, PCIe** card to a free blue PCIe slot on the computer's motherboard.
2. Move the Ethernet cable from the computer's built-in network adapter to the new PCIe network card.
 1. Above the computer, select **Back** to switch to the back view of the computer.
 2. Drag the **Ethernet cable** from the built-in port to the port on the PCIe network adapter.
3. Confirm that the computer is connected to the local network and the internet.
 1. Switch to the **Front** view of the computer.
 2. Select the **power button** on the computer case to turn on the computer.
Wait for the operating system to load.
 3. Right-click **Start** and then select **Terminal (Admin)**.
 4. From the PowerShell prompt, type **ping 192.168.0.10** and then press **Enter** to test connectivity to the local network server.
 5. From the PowerShell prompt, type **ping 198.28.2.254** and then press **Enter** to test connectivity to the internet.