

CompTIA A+ Core 1 Playbook

IT Labs

Prepared by Garrick White

6.1.4 Connect a Cable Modem

You are working on a small office/home office (SOHO) network. You have just signed up for cable Internet access for the network. The cable company has installed the line into your home and given you a preconfigured modem for your network.

Your task in this lab is to:

- Connect the components to make the Internet connection.
 - Add the cable modem to the Workspace.
 - Connect the modem to the ISP's cable line using the RG-6 coaxial cable.
 - Connect the computer to the cable modem using a Cat6a Ethernet cable.
 - Use the AC to DC power adapter to plug in the modem.
- Check the computer to confirm that it's properly connected to the Internet.

In this lab, the modem was preconfigured with the correct settings to make the connection to the Internet Service Provider (ISP) and the Internet.

To complete this lab:

- Add the cable modem/router to the Workspace. Connect the modem to the WAN connection using the RG-6 coaxial cable.
- Connect the computer to the cable modem using a Cat6a Ethernet cable.
- Use the AC to DC power adapter to plug in the modem.

Complete the following steps:

1. On the Inventory, expand the **Networking Devices** category.
2. Drag the cable modem from the Inventory to the Workspace.
3. To connect the modem to the Internet connection, switch to the back view of the cable modem.
4. On the Inventory, expand the **Cables** category.
5. Select the RG-6 coaxial cable.
6. In the Selected Item Connection window, drag a connector to the port on the cable modem.
7. In the Selected Item Connection window, drag the other connector to the port on the wall plate.
8. To connect the computer to the cable modem, switch to the back view of the computer.
9. On the Inventory, select the Cat6a Ethernet cable under the Cables category.
10. In the Selected Item window, drag a connector to the Ethernet port on the cable modem.
11. In the Selected Item window, drag the unconnected end of the Ethernet port to the computer.
12. To plug in the cable modem, select the power adapter on the Inventory.
13. In the Selected Item window, drag the DC power connector to the port on the cable modem.
14. In the Selected Item window, drag the AC adapter end to the power outlet.
15. Click the Windows icon on the monitor.
16. Hover over the network icon in the bottom-right corner of the screen to confirm that it's connected to the Internet.